



DRK 1/10 SCALE DRAG RACE ESC

User Manual for Firmware D1.0

1. Introduction

The DRK sensed Electronic Speed Controller is the ultimate in engineering design from Maclan Racing. Our commitment to quality and exhaustive track testing ensures that the DRK ESC gives you the smoothest power band and reliable performance in the most demanding R/C conditions.

Please read the following instructions carefully before installing your new DRK system.

2. What's New on the new D1.0 firmware

- Specifically designed for No Prep Drag Race with proven results and extended track testing.
- All new 3-STAGE LAUNCH POWER CONTROL.
- All new throttle mapping for easiest drive with 3-STAGE LAUNCH CONTROL.
- Hi-Res data logging 0.1 sec/ record
- Optimized design to work with Maclan DRK motors.

3. Precautions

- For the best performance, we recommend using DRK ESC with Maclan Racing DRK series motors.
- Never operate your DRK ESC without the capacitor module. It will cause permanent damage to the ESC and void factory warranty.
- DRKESC is a high end racing product that offers many tuning parameters. If you are not well versed in ESC setup, we have numerous factory default profiles to get you started. If you need help with detailed settings, please contact Maclan directly for assistance.
- Maclan Racing allows control of turbo/boost timing set up in the ESC. Any ESC damage caused from excessive turbo/boost will not be covered under warranty. This method of tuning the ESC should be done with EXTREME caution and a good knowledge of boost profiles.
- Never "free rev" and brake the motor and ESC system with no load. It can cause extreme spikes that can damage both the motor and ESC, and moreover, will void the factory warranty.
- Do not connect reversed voltage. This will damage the ESC and void the factory warranty.
- Pay attention to the motor and ESC timing. More timing will generate more heat on both the ESC and the motor.
- Do not leave batteries plugged into the ESC when not in use. This will prevent short circuits and over discharging of the battery.
- Always monitor both the ESC and motor temperature after running them. Temperature should never exceed 180 degrees Fahrenheit.
- DRK ESC adapts a high performance switching BEC. This requires a high quality radio system. **2.4G and higher quality FM radio systems** are the most suitable to work with the DRK system. AM radio systems can cause noise that results in poor performance or operation failure of the DRK system.

4. Features

- High performance 32-bit CPU for high speed and accurate processing.
- All new DRK firmware algorithms for the strongest ever throttle and drag race launch performance.
- Upgraded Hi-Res data logging (0.1 sec/ record)
- All new DRK capacitor module for the best performance and protection.

- All aluminum structure with omni directional heat sink for maximum airflow and optimum cooling performance.
- All detachable connectors with several optional length cables.
- Adjustable throttle and brake PWM frequency for fine tuning.
- Advanced Boost/Turbo/Over-Boost system for top level drag racing.
- Motor/ESC temperature protection and low voltage protection.
- MS Windows compatible software for data logging, programing, and firmware updating.

5. Specifications

Scale: 1/10th Brushless Sensored/Sensorless ESC

Continuous Current: 160A

MOSFET Rated current: 400A/phase

Power input: 2S Li-Po

BEC output: Linear Mode 6V to 7.4V, 4A

Wire input: Black-12AWG-200mm*2

Wire output: Black-12AWG-200mm*3

Cooling Fan: 30x30x10mm high voltage turbo fan

Motor Limit: Brushless Sensored 3.5T

Dimension: 40x30x19mm (without fan)

Net Weight: 48g (without wires and capacitor module)

6. DRK Programming Parameters

Parameter 1: SBEC Voltage

Options are from 5.0V to 7.4V in 0.1V Increments.

A higher voltage will make servos react faster at the expense of a shorter life span. However, do not set SBEC Voltage above the servo manufacturer's recommended voltage.

Parameter 2: Forward Power

Options are from 50% to 100% in 1% Increments. This setting allows you to limit the forward power.

Parameter 3: Reverse Power

Options are from 0% to 100% in 1% Increments. This setting allows you to limit the reverse power.

Parameter 4: Sensor Mode

Options are Full Sensored and Smart Sense

The Full Sensored mode will operate the ESC in sensed only mode. It will provide the highest performance and smoothest power at all times. The Smart Sense mode will allow the Esc to operate with either a sensorless or sensed motor. This option can be helpful in the case of sensor wire malfunction or failure.

Parameter 5: Motor Rotation

Options are normal and reverse.

This allows for the changing of motor rotation for some specific chassis that require to run a reversed motor rotation.

Parameter 6: Battery Cut Off

Options are Disable, 2.9V to 7.4V in 0.1V increments.

This parameter monitors the Li-Po pack voltage. If the voltage drops to the setup value, the ESC will reduce the power output to the motor to avoid battery damage.

Parameter 7: Motor Temperature Cut

Options are Disable/ 160 degrees F to 230 degrees F

This parameter displays both Fahrenheit and Celsius (°F and °C) for easier reading.

When the motor reaches the setup temperature value, the ESC will reduce the power output to the motor to 30% to avoid overheat damage.

Note: This temperature is read from the sensor unit circuit inside the motor can. There can be discrepancies between the temperature that you capture on the outside of the motor can and what the sensor board is indicating.

Parameter 8: ESC Temperature Cut

Options are Disable/ 160 degrees F to 230 degrees F.

This parameter displays both Fahrenheit and Celsius (°F and °C) for easier reading. When the ESC reaches the setup temperature value, the ESC will reduce the power output to the motor to 30% to avoid overheat damage. Note: This temperature is read from the CPU temperature sensor. It may be different from the temperature that you capture from the ESC heat sink.

Parameter 9: Brake Strength

Options are 0% (Disabled) to 100%, in 1% Increments.

A lower Brake Strength percentage will have less powerful brakes, while a higher percentage will have stronger brakes.

Parameter 10: Drag Brake

Options are 0 (disable) to 100% in 1% Increments.

This function will provide a drag force when the throttle is released to the neutral position.

Parameter 11: Throttle Punch

Options are 1% to 100% in 1% Increments.

A lower Throttle Punch percentage will have a slower throttle response and feel softer initially. A higher Throttle Punch percentage will have a faster throttle response.

Parameter 12: Dead Band

Options are 1% to 10% in 1% Increments

This is the amount of "play" when the throttle is engaged. A setting of 'Off' will make the throttle engage more instantaneously, while 'Wide' would require more trigger movement.

Warning: Turbo function is an advanced features for experienced users, and if used incorrectly can damage the ESC or motor system. Make sure to monitor temperature levels in both the speed controller and motor carefully, and adjust gearing as needed. Any system damage caused by boost/turbo/over boost will not be covered by our factory warranty.

Parameter 13: Turbo Timing

Options are 0 (Disable) to 60 degrees in 1 degree increments.

This sets the maximum advanced timing at the time of full throttle. It often is utilized on long straightaways to reach higher top speed.

Parameter 14: Turbo Up Slew Rate

Options are Level 1 to 10.

This sets how fast the ESC reaches the maximum advanced top speed timing. The larger number will have more aggressive top speed acceleration while the smaller number will have smoother feeling.

Parameter 15: Turbo Delay

Options are 0/0.05/0.1/0.15/0.2/0.25/0.3/0.35/0.4/0.45/0.5/0.55/0.6/0.65/0.7/0.75/0.8/0.85/0.9 sec.

When this parameter is set to 0, the Turbo will be activated right after the throttle trigger is moved to the full throttle position. When it is set to a value, the turbo will be held for the selected delay period. This will provide flexibility for different track layouts.

Parameter 16: 1st Stage Power

Options are 1% to 100% in 1% Increments.

It sets the power output of 1st stage launch power control.

Parameter 17: 1st Stage Time

Options are 0.2 sec to 2.5 sec in 0.1sec Increments

It sets the time duration of 1st stage launch power control.

Parameter 18: 2nd Stage Power

Options are 50% to 100% in 1% Increments.

It sets the power output of 2nd stage launch power control.

Parameter 19: 2ndt Stage Time

Options are 0.2 sec to 2.5 sec in 0.1sec Increments

It sets the time duration of 2nd stage launch power control.

Parameter 20: 3rd Stage Power

Options are 80% to 100% in 1% Increments.

It sets the power output of 3rd stage launch power control.

DRK ESC Parameters Table

	Parameters	Values
General	SBEC Voltage	5.0V to 7.4V
	Forward Power	50% to 100%
	Reverse Power	0% to 100%
	Sensor Mode	Full Sensored/ Smart Sense
	Motor Rotation	Normal/ Reverse
Protection	Battery Cut Off	Disable/ 3.0V to 7.4V
	Motor Temperature Cut	Disable/ 160 degrees F to 220 degrees
	ESC Temperature Cut	Disable/ 160 degrees F to 220 degrees
Brake	Brake Strength	0% (disable) to 100%
	Drag Brake	0% to 100%
Throttle	Throttle Punch	1% to 100%
	Dead Band	1% to 10%
Advanced Timing	Turbo Timing	0 to 60 Degrees (1 degree incremental)
	Turbo Up Slew Rate	Level 1 to 10
	Turbo Delay (sec)	0 to 0.9 sec (0.05 sec incremental)
Launch Power Control	1st Stage Power	1% to 100%
	1st Stage Time (sec)	0.2 to 2.5
	2nd Stage Power	50% to 100%
	2nd Stage Time (sec)	0.2 to 2.5
	3rd Stage Power	80% to 100%

7. Factory Profiles

The DRK ESC has 6 preset profiles that was designed for 3.5T/4.0T/4.5T motors in low or high traction conditions. You can select a corresponding profile for your application, then make fine adjustments for the actual track condition. You can also reload factory default settings for each profile via the ProLink, Maclan Link app, or a PC. You can also fine tune all parameters in each profile to meet your needs.

8. Data logging

The Maclan data logging function records system info in the ESC's CPU memory. This includes throttle/ brake position (on mobile Maclan Link App only), motor RPM, ESC and motor temperature. The DRK ESC data logging is designed to display high resolution with 0.1 sec / line recording. When viewing data through the Maclan ProLink or the Maclan Panel software, it will show you the maximum and minimum of all values. When viewing data through the mobile Maclan Link App, you will receive much more detailed information broken down into sessions.

9. Service & Warranty

Your Maclan DRK ESC is guaranteed to be free from defects in materials and workmanship for a period of 120 days. Your **original receipt** showing the item and the date and place of purchase is required with your warranty service application. An ESC that is found to have been mishandled, abused or used incorrectly, including use in an application other than that for which the ESC is intended, will not be covered under the warranty. Maclan Racing has no control over the use of the ESC application with other electronic devices such as motors and batteries. Maclan Racing is not liable for any loss or damage, whether direct or indirect, incidental, or consequential, or any situation from the use, misuse or abuse of the product. Your DRK ESC is not a toy. This product is not intended for use by a child under age of 14 without adult supervision. The DRK ESC generates a lot of power that could result in physical injuries. By setting up, connecting or operating the product, the user accepts all related liabilities.

For service, please visit www.hadma.com and follow the service instructions for the quickest turnaround time.

For all technical questions, please visit www.maclan-racing.com for the corresponding FAQ, or e-mail your question to service@hobbyauthority-dist.com

Maclan Racing offers a product trade-in program and reserves the right for all warranty applications. Please visit www.maclan-racinng.com for details.

www.maclan-racing.com
Made in Taiwan




DRK

Accelerated Innovation

1. DRK ESC Physical Diagram

- 1 Fan power port
- 2 RX receiver port
- 3 Power switch port
- 4 Micro USB host port
- 5 LED #1
- 6 LED #2






2. Power on DRK ESC

There are 2 ways to power on and off DRK ESC; with the included slide switch plugged into the ESC, it will be controlled by the switch. If the slide switch is not installed, the ESC power is controlled by the battery connection and the ESC will power on as soon as the battery is plugged in. It will then power off when the battery is unplugged.

3. Radio Calibration

- a. Power on your transmitter with the ESC off.



- b. Hold FULL BRAKE on your transmitter while powering on the ESC. You will get a confirmation tone. You will see a solid RED on LED #1 with flashing ORANGE LED #2. (The flashing ORANGE LED means the ESC is capturing the FULL BRAKE position)
- c. When the ORANGE LED turns solid, you will get a second confirmation tone. The LED #2 will begin flashing BLUE. Apply FULL THROTTLE now. (The flashing BLUE LED #2 means the ESC is capturing the FULL THROTTLE position)
- d. When the BLUE LED turns off with a third confirmation tone, release the throttle to neutral position. The ESC is now capturing the neutral position.
- e. You will get a power-on tone to confirm the calibration process is complete.

****A complete radio calibration video could be found from Maclan Racing web site and its YouTube channel. Visit the web site to view the complete process.**

4. Programming DRK ESC

There are some options to program your Maclan DRK ESC. You can connect the DRK ESC to Maclan ProLink (sold separately) via the receiver (RX) port on the ESC, or to the micro USB port to change settings. You can connect DRK ESC to a Windows 7/10 PC via its micro USB port to change settings. You will need to download Maclan Panel PC software from Maclan-Racing.com web site. You can also connect DRK ESC to an Android based mobile device (Android OS version 5.0 and up) to change settings by Maclan Link app with USB connection. Or, you can use Maclan AirLink WIFI module to wirelessly connect your Android based mobile device (Android OS version 5.0 and up) or Apple iPhone (iOS 13 and up) by Maclan Link app.

5. Firmware Update

1. Download the latest firmware from www.maclan-racing.com
2. Connect MMax Pro USB to a Windows 7 or Windows 10 PC
3. Run the firmware updating software and follow the instruction on the screen

6. LED Indicators

	LED 1	LED 2	Actions
Power on & no receiver signal	Red	Blue	LED 1 & 2 flash every sec simotaneously
Power on & ROAR blinky mode	Red	Blue & Orange	LED 1 (solid) + LED 2 (alternating blue & orange)
Power on & race open mode	Red	Blue	LED 1 (solid red) + LED 2 (solid blue)
Power on & vehicle runs forward	Red	Blue	LED 1 (solid Red) + LED 2 flashes blue rapidly to solid (full throttle)
Power on & vehicle brakes	Red	Orange	LED 1 (solid Red) + LED 2 flashes orange rapidly to solid (full brake)
Low voltage cut off	Red	Blue	LED 1 & 2 flash every sec alternaty with motor beeping
ESC temperature cut off	Red	Orange	LED 1 & 2 flash twice every sec alternaty with motor beeping
Motor temperature cut off	Red	Orange	LED 1 & 2 flash 3 times every sec alternaty with motor beeping